



ComNet Ericsson Panther 600P Exterior Case Disassembly

The exterior case must be removed in order to access any of the internal components. Follow this guide to do so.

Written By: Kellan Sells



INTRODUCTION

This guide shows how to remove the antenna, volume and channel dials, and the exterior case.

TOOLS:

- [T15 Torx Screwdriver](#) (1)
 - [iFixit Opening Tools](#) (1)
-

Step 1 — Locate the release button.



- Look for the release button on the back of the radio.
- Press the button and pull down on the battery at the same time. The battery will come free.

Step 2 — Antenna



- Twist the antenna counter-clockwise to unscrew it from the antenna jack.

Step 3 — Dials



- Pull up on the dials to remove them from the underlying pegs.

Step 4 — Exterior Case



- Using a T15 Torx screwdriver, unscrew the two screws.
- Using a plastic opening tool, pry the internal case from the external case.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-07-13 04:48:33 PM.